


20209J 24" W x 28" H x 12" D

WALL CABINET

INSTRUCTION MANUAL



**IF ANY PARTS ARE
MISSING OR DAMAGED,
OR IF YOU HAVE ANY
QUESTIONS, PLEASE CALL
1-866-221-8146.**

www.salmonboy.ca



Read and understand this instruction manual thoroughly before using the product. It contains important information for your safety, as well as operating and maintenance advice.

Keep this instruction manual for future use. Should this product be passed on to a third party, this instruction manual must be included.

TABLE OF CONTENTS 2



TECHNICAL SPECIFICATIONS	3
SAFETY GUIDELINES	4
EXPLODED VIEW	5
PACKAGE CONTENTS	6-7
ASSEMBLY INSTRUCTIONS	8-11
WARRANTY	12
ADDITIONAL AND SPARE PARTS	13



3 TECHNICAL SPECIFICATIONS

Component	Maximum load
Cabinet	270 lb (122.5 kg)
Middle shelves	75 lb (34 kg) (each)
Bottom panel	120 lb (54.5 kg)

SAFETY GUIDELINES 4



Safety guidelines

Crucial information that relates to protecting your personal safety and to prevent equipment issues are contained in this manual. It is in your best interest to read this manual carefully beforehand and understand it thoroughly before assembling and using the product. Below are the symbols used to indicate this information.



CAUTION!

Potential hazard that may result in moderate injury or damage to equipment.

Note - The word “Note” is used to inform the reader of something the user needs to know about the tool.

SAFETY RECOMMENDATIONS

These safety precautions are for the personal safety of the user and others working on the product. Failure to comply with these instructions may cause in serious or even fatal injury, property damage and/ or equipment damage. Take time to read the instructions and fully understand them.




CAUTION!

Potential hazard that may result in moderate injury or damage to equipment.


- Place the cabinet on a level surface.
- This product is intended for indoor use only.
- When cleaning use a soft damp to clean the cabinet.
- Do not stand on cabinet, and do not use it as a scaffold.
- Please do not exceed the weight limit specified for this product.
- Any assembly or maintenance of the product must be carried out by adults only.
- Arrange for the necessary man power when assembling and moving the cabinet.
- Check all screws periodically and tighten them, if required.

5 EXPLODED VIEW

For door handle at left side











For door handle at right side











PACKAGE CONTENTS 6



Name	Part No.	Qty	Illustration
Left panel	# 1	1	
Top / bottom panel	# 2	2	
Right panel	# 3	1	
Upper back panel	# 4	1	
Lower back panel	# 5	1	
Middle shelf	# 6	2	
Left / right door	# 7	1	
Wall-hanging bracket	# 8	2	

7 PACKAGE CONTENTS

Name	Part No.	Qty	Illustration
Hook	# 9	8	
Magnet	# 10	2	
Screw (M4 x 8)	# 11	32	
Screw (M4 x 8L)	# 12	9	
Screw (M6 x 60L)	# 13	8	
Plastic anchor (not shown)	# 14	8	
Screwdriver (not shown)	# 15	1	
Keys (not shown)	# 16	2	

ASSEMBLY INSTRUCTIONS 8

Assembly preparation

- Assemble the cabinet on a clean, level surface.
- Remove all items from the packaging box and ensure that all parts listed on pages 6-7 are available.
- When installing parts that have more than one screw, tighten all screws by hand before tightening them with the screwdriver provided.

fig A

Assembly instructions

- 1.** Attach the right panel (#3) to the right side of the top panel (#2). Line up the screw holes of both the panels. screw holes and tighten them using the screwdriver (#15). (*fig A*)





fig B


- 2.** Attach the left panel (#1) to the left side of the top panel (#2). Line up the screw holes of both the panels. Insert the M4x8 screws (#11) into the screw holes and tighten them using the screwdriver. (*fig B*)



9 ASSEMBLY INSTRUCTIONS


- 3.** Attach the bottom panel (#2) between the left panel (#1) and the right panel (#3). Line up the screw holes of all the panels. Insert the M4x8 screws (#11) into the screw holes and tighten them using the screwdriver. The cabinet frame is assembled. (*fig C*)

fig C



- 4.** Attach the lower back panel (#5) and the upper back panel (#4) onto the cabinet frame. Line up the screw holes of all the panels. Insert the M4x8 screws (#11) into the screw holes and tighten them using the screwdriver. (*fig D*)


fig D



Note: Decide on the door opening direction.

- 5.** Place the cabinet frame in the upright position. Attach two magnets (#10) to the top and bottom ends of either the left panel (#1) or right panel (#3) for each magnet, depending on your decision. (*fig E*)

fig E




ASSEMBLY INSTRUCTIONS 10

Note: Decide the height for the middle shelves.

- 6.** Insert four hooks (#9) into the slots provided at the desired height for the shelves. Then, place the first shelf (#6) into the cabinet frame and push it down onto the hooks to lock it. Follow the same procedure for attaching the other middle shelf to the cabinet frame. (*fig F*)


Note: When placing the hooks, make sure they are at the same height and the hook is facing up.

fig F




- 7.** Based on your decision for the opening direction, attach the left door or right door (#7) to the cabinet frame, with the opposite end to the magnet. Line up screw holes of the door and the cabinet frame. Insert the screws into the screw holes and tighten them using the screwdriver. (*fig G*)

fig G



- 8.** The cabinet (1) is ready to be mounted on a wall. (*fig H*)

fig H




11

ASSEMBLY INSTRUCTIONS

Wall mounting


1. Choose a location for mounting the cabinet. The recommended height from the floor to the bottom of the cabinet is 63" (160 cm). (*fig I*)

fig I




2. Place the wall-hanging brackets (#8) on the chosen location. Mark screw locations provided at the ends of the wall-hanging brackets using a pencil. The distance between marked screw locations is 16" (40.6 cm). Drill a small hole of diameter 1/8" (3 mm) at the marked screw locations. (*fig J*)

fig J



3. Insert the wall plugs into the holes drilled on the wall. Then, attach the wall-hanging brackets (#8) to the wall by securing four M6 x 60L screws (#13) for each wall-hanging bracket. Hang the cabinet on the wall hanging brackets. (*fig K*)

fig K



4. The cabinet is ready for use. Use the key to lock the door of the cabinet, if desired.

WARRANTY 12






This BLACKCOMB® product carries a one-year limited warranty against defects in materials and workmanship. Subject to conditions and limitations described below, this product, if returned to us with proof of purchase within the stated warranty period and if covered under this warranty, will be repaired or replaced (with the same model, or one of equal value or specification), at our option. We will bear the cost of any repair or replacement of the product and any costs of labour relating thereto.

This warranty is subject to the following conditions and limitations :

- a. A bill of sale to verify the purchase and purchase date must be provided.
- b. This warranty will not apply to any product or part thereof that is worn or damaged or that has become inoperative due to abuse, misuse, accidental damage, neglect, or lack of proper installation, operation, or maintenance (as outlined in the applicable instruction manual or operating instructions), or that is being used for industrial, professional, commercial or rental purposes.
- c. This warranty will not apply to normal wear and tear or to expendable parts or accessories that may be supplied with the product that are expected to become inoperative or unusable after a reasonable period of use.
- d. This warranty will not apply where damage is caused by repairs made or attempted by others (i.e., persons not authorized by the manufacturer).
- e. This warranty will not apply to any product that was sold to the original purchaser as a reconditioned or refurbished product (unless otherwise specified in writing).
- f. This warranty will not apply to any product or part thereof if any part from another manufacturer is installed therein or any repairs or changes have been made or attempted by unauthorized persons.
- g. This warranty will not apply to normal deterioration of the exterior finish, such as, but not limited to, scratches, dents, paint chips, or to any corrosion or discolouring by heat, or abrasive and chemical cleaners.
- h. This warranty applies only to the original purchaser and may not be transferred. Neither the retailer nor the manufacturer shall be liable for any other expense, loss, or damage, including, without limitation, any indirect, incidental, consequential, or exemplary damages arising in connection with the sale, use or inability to use this product.




13 ADDITIONAL & SPARE PARTS

Salmon Boy Ltd. proudly provides additional and spare parts for your BLACKCOMB cabinets and workbenches. Feel free to contact us if you have any questions or need any additional, spare parts at 1-866-221-8146. Service@SalmonBoy.ca




M14 wheel module

a set of 4 rolling casters (2 with breaks)
for 20248J, 16241J, 68-6364, 68-6365, 68-1221,
68-0667 cabinets/ workbenches



M12 Leveling feet

a set of 4 leveling feet for 68-1224 workbench



Extra shelf

a shelf with 4 hooks (if the shelf needs hooks)
for 20248J, 20209J, 16236J, 16241J, 20205J, 68-0558,
68-1224, 68-1226, 68-6364, 68-6365, 68-6366, 68-1221
or 68-0667 cabinets/ workbenches



Lock set

a new lock with 2 keys